

Sizing Guide

| | SleepWeaver ANEW | | | Measurement Technique |
|-------------|------------------|---------|-------|---|
| | Small | Regular | Large | |
| Nasal Width | 1" | 1 ¼" | 1 ½" | 1.) Measure from outer left nare to outer right nare. (see diagram below) |
| Height | 3 ¼" | 3 ½" | 3 ¾" | 1.) Your measurement starts 1/2 inch down the bridge of your nose from between your eyes. (see diagram below) 2.) Your measurement ends half way between the mouth and chin. (see diagram below) |

*If measurement falls between sizes, choose smaller size

**The use of this information is not intended to replace the advice of a medical professional, sleep technician, or HME Dealer.

